JUNO SERIES

USER MANUAL

JN-6T / JN-6TW
JN-8T / JN-8TW



Lynx Pro Audio S.L.
V.20.11 Valencia, Spain - www.lynxproaudio.com - info@lynxproaudio.com

CONTENTS

INTRODUCTION

UNPACKING

SAFETY PRECAUTIONS



Hearing damage risk



Hanging / Flying



Delicate Material



Overheating / Fire risk



Electromagnetic and interferente emissions

IMPORTANT NOTE

RIGGING AND SUSPENSION SAFETY PRECAUTIONS

CABINET CONNECTIONS

Normative

Connections:

100V Tap Selector:

and impedance needed.




recommended.


Back Cover:



TROUBLESHOOTING

BRACKET INSTALLATION





JN-6T DATASHEET

JN-6T


Technical Data:

JN-6T DATASHEET

Key features

Perfectly suited for:

Dimmensions:




JN-8T DATASHEET

JN-8T

Technical Data:

Key features

Perfectly suited for:



LYNX PRO AUDIO GUARANTEE

WEEE Declaration:

CE

DECLARATION OF CONFORMITY

Lynx Pro Audio S.L.
Calle 1 - Pol. Ind. Picassent
46220 Picassent (Valencia)
SPAIN - EU
Tel.: (+34) 961 10 96 01
www.lynxproaudio.com

Juno models: JN-6T/JN-6TW/JN-8T/JN-8TW